## Unit 1 Lecture 7

#### 8085 MPU



#### Intel 8085 Pin Configuration



#### Signals and I/O Pins





## The 8085 and Its Buses

- The 8085 is an 8-bit general purpose microprocessor that can address 64K Byte of memory.
- It has 40 pins and uses +5V for power. It can run at a maximum frequency of 3 MHz.
  - The pins on the chip can be grouped into 6 groups:
    - Address Bus.
    - Data Bus.
    - Control and Status Signals.
    - Power supply and frequency.
    - Externally Initiated Signals.
    - Serial I/O ports.

#### The Address and Data Bus Systems

- The address bus has 8 signal lines A8 A15 which are unidirectional.
- The other 8 address bits are multiplexed (time shared) with the 8 data bits.
  - So, the bits AD0 AD7 are bi-directional and serve as A0 - A7 and D0 - D7 at the same time.
    - During the execution of the instruction, these lines carry the address bits during the early part, then during the late parts of the execution, they carry the 8 data bits.
  - In order to separate the address from the data, we can use a latch to save the value before the function of the bits changes.

### The Control and Status Signals

- There are 4 main control and status signals. These are:
  - ALE: Address Latch Enable. This signal is a pulse that become 1 when the ADO – AD7 lines have an address on them. It becomes 0 after that. This signal can be used to enable a latch to save the address bits from the AD lines.
  - RD: Read. Active low.
  - WR: Write. Active low.
  - IO/M: This signal specifies whether the operation is a memory operation (IO/M=0) or an I/O operation (IO/M=1).
  - S1 and S0 : Status signals to specify the kind of operation being performed. Usually not used in small systems.

# The Flags register

• There is also a flag register whose bits are affected by the arithmetic & logic operations.

OS-sign flag

The sign flag is set if bit D7 of the accumulator is set

after an arithmetic or logic operation.

○Z-zero flag

- Set if the result of the ALU operation is 0. Otherwise
- is reset. This flag is affected by operations on the accumulator as well as other registers. (DCR B).

# The Flags register

#### AC-Auxiliary Carry

This flag is set when a carry is generated from bit D3 and passed to D4. This flag is used only internally for BCD operations.

P-Parity flag

After an ALU operation, if the result has an even # of 1s, the p-flag is set. Otherwise it is cleared. So, the flag can be used to indicate even parity.

CY-carry flag

This flag is set when a carry is generated from bit D7 after an unsigned operation.

OV-Overflow flag

This flag is set when an overflow occurs after a signed operation.

# More on the 8085 machine cycles

- The 8085 executes several types of instructions with each requiring a different number of operations of different types. However, the operations can be grouped into a small set.
- The three main types are:
  - Memory Read and Write.
  - I/O Read and Write.
  - Request Acknowledge.
- These can be further divided into various smaller operations (machine cycles).

# **Opcode Fetch Machine Cycle**

- The first step of executing any instruction is the Opcode fetch cycle.
  - In this cycle, the microprocessor brings in the instruction's Opcode from memory.
    - To differentiate this machine cycle from the very similar "memory read" cycle, the control & status signals are set as follows:
      - IO/M=0, s0 and s1 are both 1.
  - This machine cycle has four T-states.
    - The 8085 uses the first 3 T-states to fetch the opcode.
    - T4 is used to decode and execute it.
  - It is also possible for an instruction to have 6 Tstates in an opcode fetch machine cycle.

# Memory Read Machine Cycle

- The memory read machine cycle is exactly the same as the opcode fetch except:
  - It only has 3 T-states
  - The s0 signal is set to 0 instead.

### The Memory Read Machine Cycle

- To understand the memory read machine cycle, let's study the execution of the following instruction:
  - MVI A, 32
- In memory, this instruction looks like:
  - The first byte 3EH represents the opcode for loading a byte into the accumulator (MVI A), the second byte is the data to be loaded.
- The 8085 needs to read these two bytes from memory before it can execute the instruction. Therefore, it will need at least two machine cycles.
  - The first machine cycle is the opcode fetch discussed earlier.
  - The second machine cycle is the Memory Read Cycle.

2000н <mark>ЗЕ</mark> 2001н <mark>З2</mark>

#### Example of an 8085 based computer



#### Example of an 8085 based computer

 System includes interfacing devices such as buffers, decoders, and latches.

\*8085 MPU module includes devices such as 8085 microprocessor, an octal latch, and logic gates.

Three machine cycles:

Opcode fetch

Memory read machine cycle

Memory write cycle

Microprocessor external communication can be divided into three categories:

Memory read and write

I/O read and write

Request acknowledge