ECE DEPARTMENT

Subject: EMI (NEC-403)

- 1. Explain the terms "accuracy", "sensitivity" and "resolution" as used for indicating instruments
- **2.** What is meant by the term 'unit' in the measurement? Define "fundamental units" and "derived units". Give examples of each.
- **3.** What is the difference between primary and secondary standards?
- **4.** What are the instrumental, environmental and observational errors? Briefly explain about each one of them.
- 5. The measured value of a capacitor is $205.3\mu\text{F}$, whereas its true value is $201.4\mu\text{F}$. Determine the relative error.
- **6.** Show that dimensions of product of voltage and current are dimensions of power.
- 7. The moving coil of a PMMC instrument has 125 turns and is of dimensions 4 cm x 2.5 cm. The flux density in the air-gap is 0.06 T. Determine the deflection when the coil carries a current of 25 mA. The spring control provides a deflection of one degree for a torque of 25 x 10⁻⁷ Nm.
- **8.** Explain the use of shunt as a device for extending the range of ammeters. What are the advantages of shunt?
- **9.** Explain the construction and working of PMMC instrument with proper diagram.
- **10.** List the three torques involved in the moving system of a deflection instrument and explains the function of each torque. How are these torques produced in PMMC instruments?
- 11. How PMMC meter can be converted into an ammeter? Explain with circuit diagram.
- **12.** How PMMC meter can be converted into a voltmeter? Explain with circuit diagram.
- 13. A moving coil galvanometer gives a deflection of 150 mm on a scale distant 2.5 m for a current of 2.5 μ A. The resistance of the moving coil of galvanometer is 250 Ω . Determiner current sensitivity, voltage sensitivity, megohm sensitivity and the deflection produced in radians by a current of 5 μ A.
- **14.** The coil of a measuring instrument has a resistance of 1 Ω and the instrument has a full-scale deflection of 250 V when a resistance of 4999 Ω is connected in series with it, find
 - (i) The current range of the instrument when used as an ammeter with the coil connected across a shunt of $\frac{1}{4999}\Omega$.
 - (ii) The value of the shunt resistance for the instrument to give a full-scale deflection of