


# DISPLACEMENT METHOD OF ANALYSIS: MOMENT DISTRIBUTION



- **Member Stiffness Factor ( $K$ )**
- **Distribution Factor (DF)**
- **Carry-Over Factor**
- **Distribution of Couple at Node**
- **Moment Distribution for Beams**
  - **General Beams**
  - **Symmetric Beams**
- **Moment Distribution for Frames: No Sidesway**
- **Moment Distribution for Frames: Sidesway**

# Member Stiffness Factor ( $K$ ) & Carry-Over Factor (COF)




Internal members and far-end member fixed at end support:

$$K = \frac{4EI}{L}$$




$$K_{(BC)} = 4EI/L_2,$$

$$K_{(CD)} = 4EI/L_3$$



Far-end member pinned or roller end support:

$$K = \frac{3EI}{L}$$




$$K_{(AB)} = 3EI/L_1,$$

$$K_{(BC)} = 4EI/L_2,$$

$$K_{(CD)} = 4EI/L_3$$

# Joint Stiffness Factor ( $K$ )




$$K_{(AB)} = 3EI/L_1$$

$$K_{(BC)} = 4EI/L_2,$$

$$K_{(CD)} = 4EI/L_3$$

$$K_{joint} = K_T = \Sigma K_{member}$$


# Distribution Factor (DF)





$$DF = \frac{K}{\Sigma K}$$


## Notes:

- far-end pinned (DF = 1)
- far-end fixed (DF = 0)




# Distribution of Couple at Node







$$L_1 = L_2 = L_3$$




# Distribution of Fixed-End Moments




$L_1 = L_2 = 8 \text{ m}, L_3 = 10 \text{ m}$







$L_1 = L_2 = 8 \text{ m}, L_3 = 10 \text{ m}$



# Moment Distribution for Beams







### Example 1

The support  $B$  of the beam shown ( $E = 200 \text{ GPa}$ ,  $I = 50 \times 10^6 \text{ mm}^4$ ).


Use the moment distribution method to:

- Determine all the reactions at supports, and also
- Draw its **quantitative shear and bending moment diagrams**, and **qualitative deflected shape**.






**Note :** Using the Slope Deflection



$$M_{BA} = \frac{3(2EI)}{8}\theta_B - 30 \quad \text{--- (1)}$$

$$M_{BC} = \frac{4(3EI)}{8}\theta_B + 16 \quad \text{--- (2)}$$



$$\sum M_B = 0: -M_{BA} - M_{BC} = 0$$


$$(0.75 + 1.5)EI\theta_B - 30 + 16 = 0$$

$$\theta_B = 6.22/EI$$

$$M_{BA} = -25.33 \text{ kN}\cdot\text{m},$$

$$M_B = 25.33 \text{ kN}\cdot\text{m}$$


$$M_{CB} = \frac{2(3EI)}{8}\theta_B - 16 = -11.33 \text{ kN}\cdot\text{m}$$





## Example 2


From the beam shown use the moment distribution method to:

- (a) Determine all the reactions at supports, and also
- (b) Draw its **quantitative shear and bending moment diagrams**, and **qualitative deflected shape**.















		$K_1 = 3(2EI)/8$	$K_2 = 4(3EI)/8$	$K_3 = 3(3EI)/8$	
DF	1	$\frac{K_1}{K_1+K_2}$	$\frac{K_2}{K_1+K_2}$	$\frac{K_2}{K_2+K_3}$	$\frac{K_3}{K_2+K_3}$
Joint couple		0.333	0.667	0.571	0.429
CO FEM		-15	26.667	-26.667	40
Dist.		-3.885	-7.782	1.905	1.437
CO			0.953	-3.891	
Dist.		-0.317	-0.636	2.218	1.673
CO			1.109	-0.318	
Dist.		-0.369	-0.740	0.181	0.137
$\Sigma$		-36.22	-13.78	-43.28	43.25









### Example 3





From the beam shown use the moment distribution method to:


- Determine all the reactions at supports, and also
- Draw its **quantitative shear and bending moment diagrams**, and **qualitative deflected shape**.





	$K_1 = 4(2EI)/6$	$K_2 = 3(EI)/9$	
	$\frac{K_1}{K_1+K_2}$	$\frac{K_2}{K_1+K_2}$	
DF	0	0.80	0.20
Joint couple		40	10
CO	20		
FEM	30	-30	101.25
Dist.		-9	-2.25
CO	-4.5		
$\Sigma$	45.5	1	49
			-120






### Example 4


The support  $B$  of the beam shown ( $E = 200 \text{ GPa}$ ,  $I = 50 \times 10^6 \text{ mm}^4$ ) settles  $10 \text{ mm}$ .

Use the moment distribution method to:


- Determine all the reactions at supports, and also
- Draw its **quantitative shear and bending moment diagrams**, and **qualitative deflected shape**.







**Note :** Using the slope deflection




$$M_{AB} = \frac{4(2EI)}{8}\theta_A + \frac{2(2EI)}{8}\theta_B + 20 - 18.75 \quad \text{--- (1)}$$

$$M_{BA} = \frac{2(2EI)}{8}\theta_A + \frac{4(2EI)}{8}\theta_B - 20 + 18.75 \quad \text{--- (2)}$$

$$\frac{(2)-(1)}{2}: M_{BA} = \frac{3(2EI)}{8}\theta_B - 30 + 9.375 - 12/2 \quad \text{--- (2a)}$$

$$M_{BC} = \frac{4(3EI)}{8}\theta_B + 16 - 28.125 \quad \text{--- (3)}$$

$$M_{CB} = \frac{2(3EI)}{8}\theta_B - 16 - 28.125 \quad \text{--- (4)}$$



$$\sum M_B = 0: -M_{BA} - M_{BC} + 15 = 0$$

$$(0.75 + 1.5)EI\theta_B - 38.75 - 15 = 0$$



$$\theta_B = 23.9/EI$$


$$M_{BA} = -8.7 \text{ kN}\cdot\text{m},$$

$$M_B = 23.72 \text{ kN}\cdot\text{m}$$

$$M_{CB} = \frac{2(3EI)}{8}\theta_B - 16 - 28.125$$

$$= \boxed{26.2 \text{ kN}\cdot\text{m}}$$






### Example 5


For the beam shown, support A settles 10 mm downward, use the moment distribution method to

(a) Determine all the **reactions** at supports


(b) Draw its **quantitative shear, bending moment diagrams**, and **qualitative deflected shape**.

Take  $E = 200 \text{ GPa}$ ,  $I = 50(10^6) \text{ mm}^4$ .








		$K_1 = 4(2EI)/3$	$K_2 = 3(1.5EI)/3$	
		$\frac{K_1}{K_1+K_2}$	$\frac{K_2}{K_1+K_2}$	
DF	0	0.64	0.36	1
Joint couple				12
CO			6	
[FEM] <sub>load</sub>			6.75	
[FEM] <sub>Δ</sub>			50	
Dist.		-40.16	-22.59	
CO	-20.08			
Σ	-20.08	-40.16	40.16	12



$\Sigma M$	-20.08	-10.16	40.16	12
------------	--------	--------	-------	----











### Example 6

- For the beam shown, support A settles 10 mm downward, use the moment distribution method to  
(a) Determine all the **reactions** at supports  
(b) Draw its **quantitative shear, bending moment diagrams**, and **qualitative deflected shape**.
- Take  $E = 200 \text{ GPa}$ ,  $I = 50(10^6) \text{ mm}^4$ .




• Overview




$R + R'C = 0$  ---- (1\*)




• Artificial joint applied



	$K_1 = 4(2EI)/3$	$K_2 = 3(1.5EI)/3$	
DF	0	$\frac{K_1}{K_1+K_2} = 0.64$	$\frac{K_2}{K_1+K_2} = 0.36$
Joint couple			12
CO		6	
[FEM] <sub>load</sub>		6.75	
[FEM] <sub>Δ</sub>		50	
Dist.		-40.16	-22.59
CO	-20.08		
©	-20.08	-40.16	40.16
			12





$\Sigma M$	-20.08	-40.16	40.16	12
------------	--------	--------	-------	----




$$+\uparrow \Sigma F_y = 0: -20.08 - 26.39 + R = 0$$

$$R = 46.47 \text{ kN}$$

• Artificial joint removed




$$\frac{6(2EI)\Delta_c}{3^2} = 100 \rightarrow \Delta = \frac{75}{EI}$$



$$\frac{6(1.5EI)(\frac{75}{EI})}{3^2} = 75$$

DF	0		
[FEM] <sub>Δ</sub>	-100	0.6 4	0.36 +37.5
		-100	1





- **Solve equation**

*Substitute  $R = 46.47 \text{ kN}$  and  $R' = 66.67 \text{ kN}$  in (1\*)*

$$46.47 + 66.67C = 0$$



$$C = -0.6970$$





# Symmetric Beam

- Symmetric Beam and Loading



$$+\curvearrowright \Sigma M_{C'} = 0: \quad -V_{B'}(L) + \frac{M}{EI} (L)\left(\frac{L}{2}\right) = 0$$

$$V_{B'} = \theta = \frac{ML}{2EI}$$



$$M = \frac{2EI}{L} \theta$$

The stiffness factor for the center span is, therefore,

$$K = \frac{2EI}{L}$$



- Symmetric Beam with Antisymmetric Loading



$$+\curvearrowright \Sigma M_{C'} = 0: \quad -V_{B'}(L) + \frac{1}{2} \left( \frac{M}{EI} \right) \left( \frac{L}{2} \right) \left( \frac{2L}{3} \right) = 0$$

$$V_{B'} = \theta = \frac{ML}{6EI}$$


$$M = \frac{6EI}{L} \theta$$


The stiffness factor for the center span is, therefore,

$$K = \frac{6EI}{L}$$

### Example 5a

Determine all the reactions at supports for the beam below.  $EI$  is constant.








$$K_{(AB)} = \frac{3EI}{L} = \frac{3EI}{4}, \quad K_{(BC)} = \frac{2EI}{L} = \frac{2EI}{6}$$

$$(DF)_{AB} = \frac{(AB)}{K_{(AB)}} = 1, \quad (DF)_{BA} = \frac{K_{(AB)}}{K_{(AB)} + K_{(BC)}} = \frac{(3EI/4)}{(3EI/4) + (2EI/6)} = 0.692,$$

$$(DF)_{BC} = \frac{K_{(BC)}}{K_{(AB)} + K_{(BC)}} = \frac{(2EI/6)}{(3EI/4) + (2EI/6)} = 0.308$$


DF	1.0	0.692	0.308
[FEM] <sub>load</sub>	0	-16	+45
Dist.		-20.07	-8.93
ΣM		-36.07	+36.07






### Example 5b


Determine all the reactions at supports for the beam below.  $EI$  is constant.




## Fixed End Moment




+



||








$$K_{(AB)} = \frac{3EI}{L} = \frac{3EI}{4} = 0.75EI, \quad K_{(BC)} = \frac{6EI}{L} = \frac{6EI}{6} = EI$$

$$(DF)_{AB} = 1, \quad (DF)_{BA} = \frac{0.75}{0.75+1} = 0.429, \quad (DF)_{BC} = \frac{1}{0.75+1} = 0.571$$


DF	1.0	0.429	0.571
[FEM] <sub>load</sub>	0	-16	16.875
Dist.		-0.375	-0.50
ΣM		-16.375	16.375








# Moment Distribution Frames: No Sidesway




### Example 6

From the frame shown use the moment distribution method to:

- (a) Determine all the **reactions** at supports
- (b) Draw its **quantitative shear and bending moment diagrams**, and **qualitative deflected shape**.







$$K_{AB} = K_{BC} = 3(2.5EI)/5 = 1.5 EI$$




$$K_{BD} = 4(3EI)/4 = 3EI$$

						C
Member	AB	BA	BC	BD	DB	CB
DF	1	0.25	0.25	0.5	0	1
Joint load		-10	-10	-20		
CO					-10	
FEM		-45	25			
Dist.		5	5	10		
CO	0	-50	20	-10	5-5	0




Member	$AB$	$BA$	$BC$	$BD$	$DB$	$CB$
$\Sigma$	<b>0</b>	<b>-50</b>	<b>20</b>	<b>-10</b>	<b>-5</b>	<b>0</b>






# Moment Distribution for Frames: Sidesway




# Single Frames



$$0 = R + C_1 R'$$

# Multistory Frames






### Example 7


From the frame shown use the moment distribution method to:

- (a) Determine all the reactions at supports, and also
- (b) Draw its **quantitative shear** and **bending moment diagrams**, and **qualitative deflected shape**.

$EI$  is constant.




• Overview



$$R + C_1 R' = 0 \quad \text{-----(1)}$$


- Artificial joint applied (no sidesway)

Fixed end moment:




Equilibrium condition :

$$\sum F_x = 0: A_x + D_x + R = 0$$



5.78 kN·m




5 m

A

$A_x = 1.73 \text{ kN}$

2.88 kN·m

2.72 kN·m



5 m

D

$D_x = 0.81 \text{ kN}$


1.32 kN·m

	A	B		C		D
DF	0	0.50	0.50	0.50	0.50	0
FEM			10.24	-2.56		
Dist.		-5.12	-5.12	1.28	1.28	
CO	-2.56	0.64	-2.56		0.64	
Dist.		-0.32	-0.32	1.28	1.28	
CO	-0.16	0.64	-0.16		0.64	
Dist.		-0.32	-0.32	0.08	0.08	
CO	-0.16	Equilibrium condition : 0.04		-0.16		0.04
Dist.		$\pm 0.02 F_x = 0.02$		1.73	0.08	0.08 = 0
$\Sigma$	-2.88	-5.78	5.78	$R = -0.92 \text{ kN}$		1.32

- **Artificial joint removed ( sidesway)**




**Fixed end moment:**

Since both  $B$  and  $C$  happen to be displaced the same amount  $\Delta$ , and  $AB$  and  $DC$  have the same  $E$ ,  $I$ , and  $L$  so we will assume fixed-end moment to be  $100 \text{ kN}\cdot\text{m}$ .



Equilibrium condition :

$$\overset{+}{\rightarrow} \Sigma F_x = 0: A_x + D_x + R' = 0$$



	A	B	C	D
DF	0	0.50	0.50	0
FEM	100	100	100	100
Dist.		-50	-50	-50
CO	-25.0	-25.0	-25.0	-25.0
Dist.		12.5	12.5	12.5
CO	-1.56	-1.56	-1.56	-1.56
Dist.		0.78	0.78	0.78
CO	0.39	0.39	0.39	0.39
Dist.		-0.195	-0.195	-0.195
Σ	80	60	-60	80

Equilibrium condition:  $\sum F_x = 0$ :

$$-28 - 28 + R' = 0$$


$$R' = 56 \text{ kN}$$



Substitute  $R = -0.92$  and  $R' = 56$  in (1) :

$$R + C_1 R' = 0$$


$$-0.92 + C_1(56) = 0$$

$$C_1 = \frac{0.92}{56}$$





Bending moment diagram (kN·m)




Deflected shape




### Example 8

From the frame shown use the moment distribution method to:

- Determine all the reactions at supports, and also
- Draw its **quantitative shear and bending moment diagrams**, and **qualitative deflected shape**.




• Overview



$$R + C_1 R' = 0 \quad \text{-----(1)}$$

• Artificial joint applied (no sidesway)




	A	B	C	D
DF	0	0.471 0.529	1.00 1.00	0
FEM Dist.	15.00	-15.00 7.065		
CO	3.533			
$\Sigma M$	18.53	-7.94	7.94	

$$K_{BA} = 4(2EI)/3 = 2.667EI$$

$$K_{BC} = 3(3EI)/3 = 3EI$$

$$K_{CD} = 3(4EI)/4 = 3EI$$




$$\rightarrow \Sigma F_x = 0:$$

$$60 - 33.53 - 0 + R = 0$$

$$R = -26.47 \text{ kN}$$

- Artificial joint removed ( sidesway)


- Fixed end moment





Assign a value of  $(FEM)_{AB} = (FEM)_{BA} = 100 \text{ kN}\cdot\text{m}$

$$\frac{6(2EI)\Delta}{3^2} = 100$$

$$\Delta_{AB} = 75/EI$$



	A	B	C	D
DF	0	0.471 0.529	1.00 1.00	0
FEM	100	100		56.25
Dist.		-47.1		0
CO	-28.55			
$\Sigma$	76.45	52.9		56.25



$$\pm \rightarrow \Sigma F_x = 0:$$

$$-43.12 - 14.06 + R' = 0$$


$$R' = 57.18 \text{ kN}$$




Substitute  $R = -26.37$  and  $R' = 57.18$  in (1) :

$$R + C_1 R' = 0$$

$$-26.47 + C_1(57.18) = 0$$

$$C_1 = \frac{26.47}{57.18}$$






### Example 8

From the frame shown use the moment distribution method to:


- (a) Determine all the reactions at supports, and also
- (b) Draw its **quantitative shear and bending moment diagrams**, and **qualitative deflected shape**.

$EI$  is constant.






• Overview




$$R + C_1 R' = 0 \quad \text{-----(1)}$$

||




artificial joint applied  
(no sidesway)

+



artificial joint removed  
(sidesway)

- Artificial joint applied (no sidesway)




Equilibrium condition :  $\rightarrow \Sigma F_x = 0$ :

$$10 + R = 0$$

$$R = -10 \text{ kN} \leftarrow$$


• Artificial joint removed (sidesway)

• Fixed end moment




Assign a value of  $(FEM)_{AB} = (FEM)_{BA} = 100 \text{ kN}\cdot\text{m}$  :  $\frac{6EI\Delta_{AB}}{4^2} = 100$

$$\Delta_{AB} = 266.667/EI$$




$$\Delta_{CD} = \Delta / \cos 36.87^\circ = 1.25 \Delta = 1.25(266.667/EI) = 333.334/EI$$




$$\begin{aligned} \Delta_B &= \Delta \tan 36.87^\circ = 0.75 \Delta \\ &= 0.75(266.667/EI) \\ &= 200/EI \end{aligned}$$

$$\Delta_{BC} = 200/EI, \Delta_{CD} = 333.334/EI$$



Equilibrium condition :


$$\rightarrow \Sigma F_x = 0: A_x + D_x + R' = 0$$



$$K_{BA} = 4EI/4 = EI, K_{BC} = 4EI/4 = EI,$$

$$K_{CD} = 3EI/5 = 0.6EI$$




	A	B	C	D		
DF	0	0.50	0.50	0.625	0.375	1
FEM	100	100	-75	-75	40	
Dist.		-12.5	-12.5	21.875	13.125	
CO	-6.25		10.938	-6.25		
Dist.		-5.469	-5.469	3.906	2.344	
CO	-2.735		1.953	-2.735		
Dist.		-0.977	-0.977	1.709	1.026	
$\Sigma$	91.02	81.05	-81.05	-56.48	56.48	





Substitute  $R = -10 \text{ kN}$  and  $R' = 82.93 \text{ kN}$  in (1) :  $-10 + C_1(82.93) = 0$


$R + C_1 R' = 0$  -----(1)

$C_1 = 10/82.93$





Bending moment diagram  
(kN·m)




Deflected shape

### Example 9

From the frame shown use the moment distribution method to:


- Determine all the reactions at supports, and also
- Draw its **quantitative shear and bending moment diagrams**, and **qualitative deflected shape**.

$EI$  is constant.






• Overview




$$R + C_1 R' = 0 \quad \text{-----(1)}$$

||




+




- Artificial joint applied (no sidesway)

Fixed end moments:




Equilibrium condition :

$$\rightarrow \Sigma F_x = 0: A_x + D_x + R = 0$$



	A	B	C	D		
DF	0	0.60	0.40	1.00	1.00	0
FEM			22.5			
Dist.		-13.5	-9.0			
CO	-6.75					
$\Sigma$	-6.75	-13.5	13.5			


$K_B = 4(4EI)/3.6 = 4.444EI$ ,  $K_B = 3(3EI)/3 = 3EI$






$\pm \rightarrow \Sigma F_x = 0:$   
 $23.08 + 20 - 7.75 + R' = 0$   
 $R' = -35.33 \text{ kN}$


- Artificial joint removed (sidesway)

Fixed end moments:






Assign a value of  $(FEM)_{AB} = (FEM)_{BA} = 100 \text{ kN}\cdot\text{m} : \frac{6(4EI)\Delta_{AB}}{3.61^2} = 100, \quad \Delta_{\frac{A}{B}} = 54.18/EI$






	A	B	C	D		
DF	0	0.60	0.40	1.00	1.00	0
FEM	100	100	-52.59			30.24
Dist.		-28.45	-18.96			
CO	-14.223					
$\Sigma$	85.78	71.55	-71.55			30.24



$\pm \Sigma F_x = 0:$   
 $-68.34 - 19.49 + R' = 0$   
 $R' = 87.83 \text{ kN}$

Substitute  $R = -35.33$  and  $R' = 87.83$  in (1):  $-35.33 + C_1(87.83) = 0$

$$C_1 = 35.33/87.83$$







Diagrama momentelor




Diagrama forțelor tăietoare